



4-stack Multi-station

- Pick 4 from the stations shown below
- One G3-MS40CK (MAS0868-02) 4-stack Connection Kit Required




5-stack Multi-station

- Pick 3 from the stations shown below
- One G3-MS50CK (MAS0869-02) 5-stack Connection Kit Required
- One G3-MS40CK (MAS0868-02) 4-stack Connection Kit Required
- Two G3-MS24 (MMS0152-02) Adjustable Pulleys



8-stack Multi-station

- Pick 6 from the stations shown below
- One G3-MS80CK (MAS0870-02) 8-stack Connection Kit Required
- Two G3-MS40CK (MAS0868-02) 4-stack Connection Kits Required
- Two G3-MS24 (MMS0152-02) Adjustable Pulleys



STATIONS

Adjustable Pulley G3-MS24
(MMS0152-02)



Lat Pulldown G3-MS51
(MMS0100-02)



Triceps Pressdown G3-MS52
(MMS0101-02)



Seated Row G3-MS53
(MMS0102-02)



SAMPLE CONFIGURATIONS

Please see your Matrix sales representative for other configurations and options.

4-STACK MULTI-STATION



5-STACK MULTI-STATION




8-STACK MULTI-STATION



HOW TO CONFIGURE CONNECTOR KITS


G3-MS40CK CONNECTION KIT INCLUDES
AN UPPER CONNECTION RING,
A LOWER CONNECTION RING & HARDWARE

G3-MS80CK CONNECTION KIT
INCLUDES A CROSSOVER BAR & HARDWARE



G3-MS50CK CONNECTION KIT INCLUDES A
CROSSOVER BAR, REAR BASE, SHIELD & HARDWARE

G3-MS40CK Connection Kit



G3-MS50CK Connection Kit



G3-MS80CK Connection Kit

